

Yealink 1303075 MB Camera 6X and 12X External Camera Instructions

Home » Yealink » Yealink 1303075 MB Camera 6X and 12X External Camera Instructions

Contents

- 1 Yealink 1303075 MB Camera 6X and 12X External Camera
- **2 PRODUCT INFORMATION**
- **3 Product Usage Instructions**
- 4 FAQ
- **5 Introduction**
- 6 Before You Begin
- 7 MB-Camera Compatibility
- 8 How to Use
- 9 Manually Adjust Camera
- **10 Set Camera Presets**
- 11 Auto Framing
- 12 Speaker Tracking
- 13 PIP Mode
- **14 FAQ**
- 15 Documents / Resources
 - 15.1 References
- **16 Related Posts**



Yealink 1303075 MB Camera 6X and 12X External Camera



PRODUCT INFORMATION

Specifications

• Pixels: 8 million

• Image Sensor: Sony

• Optical Zoom: 6X or 12X

• Features: Manual adjustment (PTZ), camera preset, Auto Framing, Speaker Tracking, PIP Mode

Product Usage Instructions

Before You Begin

The MeetingBoard needs to be updated to version 155.15.0.37 or later to support the 6X Camera and version 155.15.0.46 or later to support the 12X camera.

MB-Camera Compatibility

Please refer to the Teams Room Accessories Compatibility Lists for information on MB-Camera compatibility.

How to Use

For installation instructions, please refer to MB-Camera-6X&12X Installation.

Manually Adjust Camera

The external camera can be manually adjusted. For more information, please refer to Camera Control.

Set Camera Presets

The external camera supports setting and applying camera presets in a meeting. For more information, please refer to Camera Preset.

Auto Framing

The external camera supports Auto Framing. For more information, please refer to Auto Framing.

Speaker Tracking

The external camera supports Speaker Tracking. For more information, please refer to Speaker Tracking.

PIP Mode

The external camera supports PIP Mode. For more information, please refer to PIP Mode.

FAQ

Can the MeetingBoard PTZ external camera be connected to cameras other than MB-Camera?

No, the MeetingBoard PTZ external camera can only be connected to MB-Camera and is not compatible with other cameras.

Introduction

MB-Camera is a pluggable optical zoom camera module suitable for MeetingBoard. With 8 million pixels, a Sony image sensor, and 6/12x optical zoom. It supports manual adjustment (PTZ), camera preset, Auto Framing, Speaker Tracking, and PIP Mode. After installing the external camera, the MeetingBoard will automatically switch to using the external camera. For the operation video, please refer to MB-Camera.

NOTE

After installation, the external camera will be automatically updated.

Before You Begin

The MeetingBoard needs to be updated to version 155.15.0.37 or later to support the 6X Camera and version 155.15.0.46 or later to support 12X camera.

MB-Camera Compatibility

For the MB-Camera compatibility, please refer to Teams Room Accessories Compatibility Lists.

How to Use

Installation

For more information, please refer to MB-Camera-6X&12X Installation.

Manually Adjust Camera

- Support adjusting the external cameras manually.
- For more information, please refer to Camera Control.

Set Camera Presets

- The external camera supports setting and applying camera presets in a meeting.
- For more information, please refer to Camera Preset.

Auto Framing

- The external camera supports the Auto Framing.
- For more information, please refer to Auto Framing.

Speaker Tracking

- The external camera supports the Speaker Tracking.
- For more information, please refer to Speaker Tracking.

PIP Mode

- The external camera supports the PIP Mode.
- For more information, please refer to PIP Mode.

FAQ

Can the MeetingBoard PTZ external camera be connected to cameras other than MB-Camera?

Documents / Resources



<u>Yealink 1303075 MB Camera 6X and 12X External Camera</u> [pdf] Instructions 1303075, 1303075 MB Camera 6X and 12X External Camera, MB Camera 6X and 12X External Camera, 6X and 12X External Camera, 12X External Camera, External Camera, Camera

References

- Yealink Support
- User Manual

Manuals+, Privacy Policy