

Yealink MVC-S40-C4-000 Microsoft Teams Rooms Kit **Instruction Manual**

Home » Yealink » Yealink MVC-S40-C4-000 Microsoft Teams Rooms Kit Instruction Manual






Contents

- 1 Minimum Requirements
- 2 Package Contents
- 3 Install MVC S40-C4-000
- 4 Connect MVC S40-C4-000
- **5 Initial Setup**
- **6 Features**
- **7 Supported Accessories**
- 8 Documents / Resources
 - 8.1 References


Minimum Requirements

A display connected to MCore Pro (not included). A Microsoft Teams Rooms or Skype® for Business account (not included). Wired network environment (not included).


Package Contents




SmartVision 40 Package



MCore Pro Package



MTouch E2 Package




MTouch Plus Package (Optional)

Install MVC S40-C4-000

- MCore Pro supports: mount on the wall, mount on the TV, stick to the table.
- MTouch E2 supports: put on a table, mount on a wall.
- SmartVision40 supports: put on a flat surface, mount on the wall, embed in the wall, mount on the Tabletop Mount, and mount on the Tabletop Mount.
- Install and deploy the accessories in the system according to the environment and actual needs. For how to install and deploy, please refer to the quick start guide for each product.

Connect MVC S40-C4-000



(i) NOTE

- When starting up the system for the first time, you need to connect a mouse to complete the initial configuration. We recommend using the wireless mouse and keyboard kit.
- Not included accessories requirements:
 - Display: Resolution of 1080p or higher and with an HDMI port.
 - PC: Equipped with HDMI or USB-C (support DP protocol) Port.
 - Ethernet cable: CAT5e or higher ethernet cable.
 - HDMI: Standard HDMI cable.
 - PoE switch: If you use PoE to connect speakers or cameras, you need to use PoE+.

Initial Setup

1. Press the power button on the bottom left of MCore Pro and the Microsoft Windows 11 IoT Enterprise Edition operating system will be automatically loaded after starting MCore Pro.

(i) NOTE

When starting up the system for the first time, you need to connect a mouse to complete the initial configuration. We recommend using the wireless mouse and keyboard kit. After the system is initialized, you can use MTouch E2 to complete the system login and settings, and the device will automatically start the Microsoft Teams conference system application and enter the settings page.

- 2. Select the check box on the EULA page, and then tap Next.
- 3. Enter the account, the password on the Account page, and then tap Next. Supports Microsoft Teams Rooms or Skype® for Business accounts.
- 4. On the Advanced page, configure the domain and tap Next.
- 5. Tap Finish to complete the setup wizard.

Features

Wireless Sharing



- Connect the WPP30 to the USB port of the MTouch E2.
 When pairing, the LED indicator of WPP30 is orange. When the pairing is successful, the LED indicator turns green breathing light.
- 2. Do one of the following:

For WPP30:

- a. Connect the paired WPP30 to the USB-A/USB-C port on your PC.
- b. On the WPP30, press the presentation button to share full screen.

Control SmartVision40 Camera Position

1. Tap More > to enter the Camera Control page.

Supported Accessories

For the compatible devices and the maximum number of compatible devices, please refer to Teams Room Accessories Compatibility Lists.



Documents / Resources



Yealink MVC-S40-C4-000 Microsoft Teams Rooms Kit [pdf] Instruction Manual MVC-S40-C4-000 Microsoft Teams Rooms Kit, MVC-S40-C4-000, Microsoft Teams Rooms Kit, Teams Rooms Kit, Rooms Kit

References

• User Manual

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.