

# Quick Setup

This guide outlines how to boot the Microsoft Teams Rooms System (MVC) and initialize the system for administrators.

## Before You Begin

Before setting up your MVC system, please ensure that:

- You have a Skype for Business or Microsoft Teams account.
- You have finished the steps in [Deployment & Connection](#).
- You have connected a mouse (wireless mouse kit is recommended) or a Yealink MTouch Touch Panel to your Yealink mini-PC.




### **NOTE**

For details about MVC product family, please refer to [MVC Product Family](#).

## Initial Setup

1. Once your Yealink mini-PC is powered on, it will load the Microsoft Windows 11 operating system automatically.
2. After initializing the system, the device will automatically launch the Microsoft Teams Rooms Systems and enter the setup page.

3. On the **EULA** tab, read the **Software License Term** carefully, tick the checkbox, and click **Next**.



4. On the **Account** tab:
  1. Enter the email and password of your Skype for Business or Microsoft Teams account.
  2. Go to **Supported meeting mode** and select a desired meeting mode.
  3. Enable **Modern Authentication** as needed. Modern authentication is part of a process that lets Teams know that users have already entered their credentials—such as their work email and password—elsewhere, and they shouldn't be required to enter them again to start the app. Refer to the [Microsoft article](#) for more details.
  4. Click **Next**.

The screenshot shows the 'Setup' window with the 'Account' tab selected. The left sidebar contains links for EULA, Account, Cortana, Advanced, and Finish. The main area has fields for Email (example@example.com), Password (Password), and Supported meeting mode (Microsoft Teams only). A toggle for Modern Authentication is turned on. Version information is shown at the top right: App version 4.16.40.0, Windows version 10.0.19044.2846, and Provisioning version 15. Back and Next buttons are at the bottom right.

**Setup** App version 4.16.40.0 Windows version 10.0.19044.2846 Provisioning version 15

EULA

Account

Cortana

Advanced

Finish

Email

example@example.com

Password

Password

Supported meeting mode

Microsoft Teams only

Modern Authentication

Back Next

5. On the **Advanced** tab, configure **Domain / username (optional)** and **Configure domain** as needed and click **Next**.

The screenshot shows the 'Setup' window with the 'Advanced' tab selected. The left sidebar contains links for EULA, Account, Cortana, Advanced, and Finish. The main area has fields for Exchange sign-in (usually same as Teams or Skype), Domain\username (optional), and Configure domain. Version information is shown at the top right: App version 4.16.40.0, Windows version 10.0.19044.2846, and Provisioning version 15. Back and Next buttons are at the bottom right.

**Setup** App version 4.16.40.0 Windows version 10.0.19044.2846 Provisioning version 15

EULA

Account

Cortana

Advanced

Finish


Exchange sign-in (usually same as Teams or Skype)

Domain\username (optional)

Configure domain

Back Next

6. On the **Finish** tab, click **Finish** to complete your setup.

**NOTE**

For more information on planning, deploying, and managing your Microsoft Teams Rooms system, see [Microsoft Teams Rooms](#) for more details.

## Switch Account


The MVC system has two built-in accounts. Please refer to [Switch Account](#) for more details.

## Check Network Conditions

After setting up your MVC system, you can follow the steps below to check your Yealink mini-PC network conditions and whether the MTouch is connected to the network.

1. Ensure that your mini-PC is wired to the network port by a network cable.
2. In the Microsoft Teams mode, select **More > Settings**, and enter your administrator password (default: sfb).

3. Go to **About > IPv4** to check whether the network is connected. If the IPv4 field shows an IPv4 address, means it's connected to the network. The address indicates that your device has been assigned an IP address, allowing it to communicate with other devices on the network.



#### NOTE

If the Yealink MTouch Touch Panel interface shows that “This device isn't connected to the Internet” , you need to check whether the network cable is connected correctly.

## Check Firmware Version

### Check Window Version

1. In the Microsoft Teams mode, select **More > Settings**, and enter your administrator password (default: sfb).
2. On the **About** tab, you can check the system firmware version in **App version** and **Windows version**.

**Settings**

- About
- Account
- Advanced
- Meetings
- Device
- Coordinated meetings
- Peripherals
- Select a background
- Windows Settings
- Reset Device

**App version**  
4.18.20.0

**Windows version**  
10.0.22621.2134

**Room License**  
Microsoft Teams Rooms Pro

**IP v4**  
10.50.67.96

**IP v6**  
2053:10:50:67:7e71:f872:7f47:c035

**Cortana: Off**  
Voice activation: Off  
The activation keyword can be turned on/off in the Teams Admin Center.

**Automatic password rotation: Off**

**Microsoft Teams third party notices**  
View Notice

Exit without saving | Save and exit

## Check MVC Devices Version

1. Switch to the Windows mode.
2. Open the Yealink RoomConnect application to select the desired device.
3. Select **Device Status** to check the device firmware version.

**Yealink RoomConnect**

← Return

MTouchII

- Device Status
- Device Settings
- Update Device
- Device Support

**Equipment Model**  
MTouchII [Add a remark](#)

**Firmware Version**  
126.410.0.85

**Connection Method**  
Network Cable

**Serial Number**  
803061E020002244


**Hardware Version**  
126.2.0.0.2.0.17

[Official Website](#)

## Update MVC

### Update System Firmware

#### ► Method 1: Enable Automatic Windows Update

1. In the Windows mode, select  to go to **Settings > Windows Update > Advanced options**.
2. Enable **Download updates over metered connections**.


#### ► Method 2: Update Windows Manually

1. In the Windows mode, select  to go to **Settings > Windows Update**.
2. Select **Check for updates**.

### Firmware Update

#### Update via Yealink RoomConnect

1. In Windows mode, open the Yealink RoomConnect application to select the desired device.
2. Go to **Update Device** and click **Upgrade**.



#### ❗ NOTE

You can also update device firmware in batches through the Yealink Device Management Platform. Please refer to [Firmware Update](#).

## Test Before Using

Before using the meeting room system, we recommend that the administrator complete the following steps to ensure proper functionality.

Description	Related Document
Test video: Ensure the local images can be displayed correctly during the meeting.	<a href="#">Basic Settings</a>
Test audio: Ensure the local audio collection works properly during the meeting.	<a href="#">Audio Collection</a>
Test meeting: Ensure you can enter the meeting properly.	<a href="#">Instant Meeting</a> <a href="#">Join Meeting</a>
Test screen sharing: Ensure you can use the screen sharing properly during the meeting.	<a href="#">Share Content via Cable</a> <a href="#">Share Content via WPP20</a>

## FAQ

**After the MVC device is turned on, the MTouch II interface prompts: Please connect to the console to complete the setup?**

**Cannot log in to Microsoft Teams in MVC system**